

Transitional Fitting(Brass)

SP01 Blocking fitting

Type[T]
1/8
1/4
3/8
1/2
3/4
1

SP02 Dyad male thread

Type[TxT]
1/8-1/8 1/2-1/2
1/4-1/8 3/4-1/2
1/4-1/4 3/4-3/4
3/8-1/8
3/8-1/4
3/8-3/8
1/2-1/4
1/2-3/8

SP03 Dyad female thread

Type[TxT]
1/8-1/8
1/4-1/8
1/4-1/4
3/8-1/4
3/8-3/8
1/2-1/4
1/2-3/8
1/2-1/2

SP04 Pagoda type mouth

Type[TxøS]
1/8-06 3/8-08 1/2-14 3/4-21
1/8-08 3/8-10 1/2-16 3/4-25
1/8-10 3/8-12 1/2-19 1-19
1/8-12 3/8-14 3/4-08 1-25
1/4-06 3/8-16 3/4-10 1-29
1/4-08 1/2-06 3/4-12
1/4-10 1/2-08 3/4-14
1/4-12 1/2-10 3/4-16
3/8-06 1/2-12 3/4-19

SP05 Agoda type elbow connector

Type[TxøS]
1/8-06 3/8-08
1/8-08 3/8-10
1/8-10 3/8-12
1/8-12 1/2-06
1/4-06 1/2-08
1/4-08 1/2-10
1/4-10 1/2-12
1/4-12
3/8-06

SP06 Y type forging

Type[øS]
06
08
10
12

SP07 Stretcher

Type[TxT]
1/8-1/4
1/8-3/8
1/4-3/8
1/4-1/2
3/8-1/2
3/8-3/4
1/2-3/4
3/4-1

SP08 Tee male connector

Type[T]
1/8
1/4
3/8
1/2

SP09 Tee female connector

Type[T]
1/8
1/4
3/8
1/2

SP10 Dyad elbow male connector

Type[TxT]
1/8-1/8
1/4-1/8
1/4-1/4
3/8-1/4
3/8-3/8
1/2-1/4
1/2-3/8
1/2-1/2

SP11 Dyad elbow female connector

Type[TxT]
1/8-1/8
1/4-1/4
3/8-3/8
1/2-1/2

SP12 Dyad elbow male & female connector

Type[TxT]
1/8-1/8
1/4-1/4
3/8-3/8
1/2-1/2
3/4-3/4

One Touch Fitting

SP series fitting is a kind of pneumatic tube system fitting which is made of brass. The type of fitting is so various that could meet the different needs of pneumatic tube system. They have the features of heat

SP13 One touch straight female connector

Type [øD-T]
06-1/4 10-1/4
06-3/8 10-3/8
06-1/2 10-1/2
08-1/8 12-1/4
08-1/4 12-3/8
08-3/8 12-1/2
08-1/2
10-1/8

SP14 One touch straight connector

Type [øD]
04
06
08
10
12

SP15 One touch tee connector

Type [øD]
04
06
08
10
12

SP16 One touch elbow conenector

Type [øD]
04
06
08
10
12

SP17 One touch elbow male connector

Type [øD-T]
06-1/8 10-1/8
06-1/4 10-1/4
06-3/8 10-3/8
06-1/2 10-1/2
08-1/8 12-1/4
08-1/4 12-3/8
08-3/8 12-1/2
08-1/2

SP18 One touch elbow female connector

Type [øD-T]
06-1/8 10-1/8
06-1/4 10-1/4
06-3/8 10-3/8
06-1/2 10-1/2
08-1/8 12-1/4
08-1/4 12-3/8
08-3/8 12-1/2
08-1/2

SP19 One touch straigh male connector

Type [øD-T]
06-1/8 10-1/8
06-1/4 10-1/4
06-3/8 10-3/8
06-1/2 10-1/2
08-1/8 12-1/4
08-1/4 12-3/8
08-3/8 12-1/2
08-1/2

SP20 One touch tee straight male union

Type [øD-T]
06-1/8 10-1/8
06-1/4 10-1/4
06-3/8 10-3/8
06-1/2 10-1/2
08-1/8 12-1/4
08-1/4 12-3/8
08-3/8 12-1/2
08-1/2

Block Fitting

SP21 Male connector  
w/blocking ring

Type [S-T]	
06-1/8	10-1/8
06-1/4	10-1/4
06-3/8	10-3/8
06-1/2	10-1/2
08-1/8	12-1/4
08-1/4	12-3/8
08-3/8	12-1/2
08-1/2	

SP22 Dyad head  
connector w/blocking ring

Type [S]
04
06
08
10
12

SP23 Dyad head elbow  
connector  
w/blocking ring

Type [S]
04
06
08
10
12

SP24 Dyad elbow male  
connector  
w/blocking ring

Type [S-T]	
06-1/8	10-1/8
06-1/4	10-1/4
06-3/8	10-3/8
06-1/2	10-1/2
08-1/8	12-1/4
08-1/4	12-3/8
08-3/8	12-1/2
08-1/2	

SP25 Tee connector  
w/blocking ring

Type [S]
04
06
08
10
12


SP26 Tee male connector  
w/blocking ring


Type [S-T]	
06-1/8	10-1/8
06-1/4	10-1/4
06-3/8	10-3/8
06-1/2	10-1/2
08-1/8	12-1/4
08-1/4	12-3/8
08-3/8	12-1/2
08-1/2	


Sliencer


■ Character


To reduce the noise effectively in the pneumatic system or air discharge equipment, the silencer can directly be equipped on it. With small shape, easily fixed, and good performance, good effect.


Mini silencer	Type
	BSLM-01 G1/8
	BSLM-02 G1/4
	BSLM-03 G3/8
	BSLM-04 G1/2
	BSLM-06 G3/4
	BSLM-08 G1


Sliencer	Type
	BSL-M5
	BSL-01 G1/8
	BSL-02 G1/4
	BSL-03 G3/8
	BSL-04 G1/2
	BSL-06 G3/4
	BSL-08 G1
	BSL-10 G5/4
	BSL-12 G3/2
	BSL-16 G2

Regulate silencer	Type
	BESN-01 G1/8
	BESN-02 G1/4
	BESN-03 G3/8
	BESN-04 G1/2
	BESN-06 G3/4
	BESN-08 G1

Stainless muffler	Type
	BSSV-M5
	BSSV-01 G1/8
	BSSV-02 G1/4
	BSSV-03 G3/8
	BSSV-04 G1/2
	BSSV-06 G3/4
	BSSV-08 G1

Stainless muffler	Type
	BSSM-M5
	BSSM-01 G1/8
	BSSM-02 G1/4
	BSSM-03 G3/8
	BSSM-04 G1/2
	BSSM-06 G3/4
	BSSM-08 G1

Sliencer throttle valve	Type
	BESL-01 G1/8
	BESL-02 G1/4
	BESL-03 G3/8
	BESL-04 G1/2
	BESL-06 G3/4
	BESL-08 G1

PSE plastic silencer	Type
	PSE-M5
	PSE-01 G1/8
	PSE-02 G1/4
	PSE-03 G3/8
	PSE-04 G1/2
	PSE-06 G3/4
	PSE-08 G1

PSL Plastic silencer	Type
	PSL-01 G1/8
	PSL-02 G1/4
	PSL-03 G3/8
	PSL-04 G1/2